



These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

## 2890L-KIT

### Locking Nut to Bolt Conversion Kit

---

2WD Vanagons have lug nuts on the rear wheels and lug bolts on the front. This means that if you wanted some locking wheel fasteners to protect your nice new alloy wheels you were forced to buy one set of nuts and one set of bolts. This left you with unused hardware and two separate "keys" (front and rear). With this GoWesty kit, you simply buy ONE set of locking nuts (four pieces) and convert two of them into bolts to be used in the front. **Note: If you have converted your 2WD to big brakes up front, you already have studs and you DO NOT need this kit.**

### Installation

- 1) Install the short end of the stud into the wheel lock (nut) using the included red Loctite and torque to 30-35 ft-lbs.
- 2) Apply anti-seize compound to the long end of the stud.
- 3) Torque the fastener to 85-90 ft-lbs.

GoWesty Camper Products • 1119 Los Olivos Ave, Los Osos, CA 93402 • 888-469-3789 • [www.gowesty.com](http://www.gowesty.com)



These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

## 2890L-KIT

### Locking Nut to Bolt Conversion Kit

---

2WD Vanagons have lug nuts on the rear wheels and lug bolts on the front. This means that if you wanted some locking wheel fasteners to protect your nice new alloy wheels you were forced to buy one set of nuts and one set of bolts. This left you with unused hardware and two separate "keys" (front and rear). With this GoWesty kit, you simply buy ONE set of locking nuts (four pieces) and convert two of them into bolts to be used in the front. **Note: If you have converted your 2WD to big brakes up front, you already have studs and you DO NOT need this kit.**

### Installation

- 1) Install the short end of the stud into the wheel lock (nut) using the included red Loctite and torque to 30-35 ft-lbs.
- 2) Apply anti-seize compound to the long end of the stud.
- 3) Torque the fastener to 85-90 ft-lbs.

GoWesty Camper Products • 1119 Los Olivos Ave, Los Osos, CA 93402 • 888-469-3789 • [www.gowesty.com](http://www.gowesty.com)