



These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

FUELLINE-SLEEVE
Fuel Line Abrasion Sleeve [Vanagon]

Installation Instructions

- 1) Simply slip one sleeve on each of the four lines running to/from the fuel rails and one on the section of hose running from the firewall to the T-fitting (input line).
- 2) Position the sleeves so they protect any potential chafing points.
- 3) The included zip-ties are optional and can be used to secure the ends to prevent shifting or fraying. **Note:** *This sleeve is crafted from "clean cut" material, so the ends should never fray. It is also very unlikely to move around, so the use of the zip-ties is up to you.*

GoWesty Camper Products • 1119 Los Olivos Ave, Los Osos, CA 93402 • 888-469-3789 • www.gowesty.com



These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

FUELLINE-SLEEVE
Fuel Line Abrasion Sleeve [Vanagon]

Installation Instructions

- 1) Simply slip one sleeve on each of the four lines running to/from the fuel rails and one on the section of hose running from the firewall to the T-fitting (input line).
- 2) Position the sleeves so they protect any potential chafing points.
- 3) The included zip-ties are optional and can be used to secure the ends to prevent shifting or fraying. **Note:** *This sleeve is crafted from "clean cut" material, so the ends should never fray. It is also very unlikely to move around, so the use of the zip-ties is up to you.*

GoWesty Camper Products • 1119 Los Olivos Ave, Los Osos, CA 93402 • 888-469-3789 • www.gowesty.com