



**GVW-181399 Auxiliary Power Outlet  
Assembly Installation instructions**

You need:  
Wire strippers  
Wire crimpers

Included:  
(2) LG female spade connectors

- Red wire(s) from car connect to center gold spade.
- Brown wire(s) from car connect to silver spade.
- Cut blue wire and wrap with electrical tape.



**GVW-181399 Auxiliary Power Outlet  
Assembly Installation Instructions**

You need:  
Wire strippers  
Wire crimpers

Included:  
(2) LG female spade connectors

- Red wire(s) from car connect to center gold spade.
- Brown wire(s) from car connect to silver spade.
- Cut blue wire and wrap with electrical tape.



**GVW-181399 Auxiliary Power Outlet  
Installation instructions**

You need:  
Wire strippers  
Wire crimpers

Included:  
(2) LG female spade connectors

- Red wire(s) from car connect to center gold spade.
- Brown wire(s) from car connect to silver spade.
- Cut blue wire and wrap with electrical tape.



**GVW-181399 Auxiliary Power Outlet  
Assembly Installation Instructions**

You need:  
Wire strippers  
Wire crimpers

Included:  
(2) LG female spade connectors

- Red wire(s) from car connect to center gold spade.
- Brown wire(s) from car connect to silver spade.
- Cut blue wire and wrap with electrical tape.



**GVW-181399 Auxiliary Power Outlet  
Installation instructions**

You need:  
Wire strippers  
Wire crimpers

Included:  
(2) LG female spade connectors

- Red wire(s) from car connect to center gold spade.
- Brown wire(s) from car connect to silver spade.
- Cut blue wire and wrap with electrical tape.



**GVW-181399 Auxiliary Power Outlet  
Assembly Installation Instructions**

You need:  
Wire strippers  
Wire crimpers

Included:  
(2) LG female spade connectors

- Red wire(s) from car connect to center gold spade.
- Brown wire(s) from car connect to silver spade.
- Cut blue wire and wrap with electrical tape.



**GVW-181399 Auxiliary Power Outlet  
Assembly Installation Instructions**

You need:  
Wire strippers  
Wire crimpers

Included:  
(2) LG female spade connectors

- Red wire(s) from car connect to center gold spade.
- Brown wire(s) from car connect to silver spade.
- Cut blue wire and wrap with electrical tape.



**GVW-181399 Auxiliary Power Outlet  
Assembly Installation Instructions**

You need:  
Wire strippers  
Wire crimpers

Included:  
(2) LG female spade connectors

- Red wire(s) from car connect to center gold spade.
- Brown wire(s) from car connect to silver spade.
- Cut blue wire and wrap with electrical tape.