



This is a proprietary GoWesty kit. Unauthorized reproduction of the information herein is not permitted.

Rear Hatch Screen Eurovan Winnebago 95 – 03

Required tools: Electric drill, 1/8" drill bit and Phillips head screwdriver

This installation of this screen will take roughly 1 hour, so set aside the time to do the job properly. Using the screen, find top center in the rear hatch opening. Start the install here. Drill a pilot hole and then install a snap-head screw. Snap the net into place in the top center, and work your way out, one by one, along the perimeter of the net. ***NOTE: Some of the snaps go through the plastic and into metal; some go into the plastic alone. Both work well.*** Be sure to keep the net taut between the snaps so the net does not sag. Once the snaps are installed, the Velcro at the bottom center attaches in the hatch's latch. Smooth the corners into place to create a good seal; they can even be tucked behind the hatch seal itself. The door can be opened and closed fully without danger of damaging the screen.

NOTE: Multivans already have snaps installed near these locations from the factory, but they often don't line up with the snaps on these screens. We don't recommend these screens for MV application.



That's it. You're done!