



These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

G VW-ENGEL-TETHER

Tie Down Strap for Engel Fridge [All Vanagon and Eurovan]

Installing Mounting Points

Vanagon: Replace both seat belt bolts on the passenger pedestal with the supplied eyebolts and washers. Torque to approximately 45 ft-lbs.

Eurovan Multivan/Weekender: Drill a 7/16" hole in both sides of the seat pedestal, at the top and rear of the large stamped indentation, leaving at least 0.5" between the center of the hole and the lip of the indentation to leave room for the shoulder of the eyebolt to sit flat. Insert the eyebolts and secure with the washers and nuts (the seat will need to be slid forward to access the back of the eyebolts). Torque to approximately 45 ft-lbs.

Eurovan Winnebago Camper: Remove the passenger side, rear pedestal bolts and install the L-brackets with the included longer bolts, using the spacers under the brackets. Torque to approximately 45 ft-lbs.

Installing Fridge in Vehicle

- 1) Clip the included carabiner through the small loop of webbing on the strap. Pinching the sides of the webbing in where it seats in the small end of the carabiner helps it to sit cleanly.
- 2) Loop the webbing through the fridge handle and insert it into the cam buckle in a manner that leaves the cam buckle and excess webbing hanging down away from the fridge so it is easy to adjust.
- 3) Place the fridge in the van behind the passenger seat and attach the carabiners to the eyebolts or L-brackets as appropriate. Tighten up the straps and tuck any excess webbing out of the way. *Note: The webbing is made with some extra length to increase the potential functionality of the strap, but it can be cut to any convenient length and sealed with heat to prevent unravelling.*

GoWesty Camper Products • 1119 Los Olivos Ave, Los Osos, CA 93402 • 888-469-3789 • www.gowesty.com

Page 1 of 1



These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

G VW-ENGEL-TETHER

Tie Down Strap for Engel Fridge [All Vanagon and Eurovan]

Installing Mounting Points

Vanagon: Replace both seat belt bolts on the passenger pedestal with the supplied eyebolts and washers. Torque to approximately 45 ft-lbs.

Eurovan Multivan/Weekender: Drill a 7/16" hole in both sides of the seat pedestal, at the top and rear of the large stamped indentation, leaving at least 0.5" between the center of the hole and the lip of the indentation to leave room for the shoulder of the eyebolt to sit flat. Insert the eyebolts and secure with the washers and nuts (the seat will need to be slid forward to access the back of the eyebolts). Torque to approximately 45 ft-lbs.

Eurovan Winnebago Camper: Remove the passenger side, rear, pedestal bolts and install the L-brackets with the included, longer bolts, using the spacers under the brackets. Torque to approximately 45 ft-lbs.

Installing Fridge in Vehicle

- 1) Clip the included carabiner through the small loop of webbing on the strap. Pinching the sides of the webbing in where it seats in the small end of the carabiner helps it to sit cleanly.
- 2) Loop the webbing through the fridge handle and insert it into the cam buckle in a manner that leaves the cam buckle and excess webbing hanging down away from the fridge so it is easy to adjust.
- 3) Place the fridge in the van behind the passenger seat and attach the carabiners to the eyebolts or L-brackets as appropriate. Tighten up the straps and tuck any excess webbing out of the way. *Note: The webbing is made with some extra length to increase the potential functionality of the strap, but it can be cut to any convenient length and sealed with heat to prevent unravelling.*

GoWesty Camper Products • 1119 Los Olivos Ave, Los Osos, CA 93402 • 888-469-3789 • www.gowesty.com

Page 1 of 1