



These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

## GVW-SKIDPLATE-SUPPORTS

### Under-Run Bar Supports for Syncro

#### Instructions:

- Assemble each support bracket set as shown in the diagram to the right. Make sure to apply the included ant seize.
- Both support brackets will be installed on the factory under-run bars just in front of the frame rail located forward of the transmission. The brackets will distribute some of the load to the uni-body strengthening the stock under-run bars. Install the bracket assemblies between the frame rail and the under-run bars like to the pictures below. 10mm bolts, washers and nuts are included to attach the bracket assemblies to the under-run bars.

