



These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

GW-STORAGE-BOX (GoWesty Storage Box for Swing Away System)

The storage box must be mounted using a Universal Carrier and Tray Offset Bracket, as it provides additional vertical support to the box. **Never** install the box on the swing arm by itself—the additional support of the Universal Carrier with Offset Bracket is needed to ensure proper function.

INSTALLATION

1. Bolt the Universal Carrier and Offset Bracket to the swing arm using the rear two bolts only. Center the box on the bracket, and mark the bottom mounting holes on the box up through the arm/carrier/bracket (a silver Sharpie works well).
2. To mark the hole on the back, use a small drill bit to drill a pilot hole through the rivet nut that is positioned toward the top of the box. Be sure you keep your drill bit straight and level.
3. Remove the box and drill the holes to 5/16" or 8 mm.
4. Bolt down the bottom of the box using the hardware included with the swing arm and the 8 additional washers (small washer stacked on top of large fender washer).
5. Fasten the rear of the box using the included bolt, spacer, washers, and nut. Use the large metal washer on the inside of the box and the spacer and rubber washer between the box and upright. Fasten the bolt through the existing rivet nut in the universal carrier.
6. Check to make sure everything is tight.
7. Enjoy your extra storage!

