



These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

GoWesty Hook-Up Box Installation Instructions

City Water

- Remove the 90-degree fitting from the back of your original hook-up and transfer it to the new one. A bit of Teflon tape or pipe thread sealant is suggested for a leak-free fit.
- It is recommended to make all connections and test for leaks before reinstalling it to the body of the vehicle.
- To operate, simply install the quick-disconnect fitting on the garden hose and click it onto the hook-up.
- Your GoWesty city water hook-up box has a built-in check valve that doubles as an over-pressure relief valve. The rubber ball in the hook-up will blow out if too much pressure is introduced into the system, thereby avoiding the possibility of breaking anything inside your Westy and causing a watery mess. When connecting an external water source to this hook-up box, we highly recommend one of our water pressure regulators. Water pressure above 55psi can not only cause damage inside your Westy, but it can also cause the check valve ball in the hook-up to blow out upon disconnecting the water source. Water freezing in the system can do the same, so we recommend always draining the system. To drain the city water plumbing, open the faucet to the city water position and, using a ball point pen, push in on the check valve ball at the hook-up point. Water should drain out sufficiently to keep the system from rupturing under freezing conditions.

Tank Filler

- Reinstall the fill and vent hoses onto the new hook-up the same way they came off the old one. Be sure the hoses are clamped securely and test the connections for leaks before reinstalling to the body of the vehicle.
- To operate, simply install the quick-disconnect fitting on the garden hose and click it onto the hook-up.
- When filling your tank, watch closely and disconnect the hose as soon as you see water appear (5 minutes or less). A bit of leaking from the vent hole after disconnecting is normal and will subside quickly.

(over)

GoWesty Camper Products • 1119 Los Olivos Ave, Los Osos, CA 93402 • (888) 469-3789 • www.gowesty.com



These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

GoWesty Hook-Up Box Installation Instructions

City Water

- Remove the 90-degree fitting from the back of your original hook-up and transfer it to the new one. A bit of Teflon tape or pipe thread sealant is suggested for a leak-free fit.
- It is recommended to make all connections and test for leaks before reinstalling it to the body of the vehicle.
- To operate, simply install the quick-disconnect fitting on the garden hose and click it onto the hook-up.
- Your GoWesty city water hook-up box has a built-in check valve that doubles as an over-pressure relief valve. The rubber ball in the hook-up will blow out if too much pressure is introduced into the system, thereby avoiding the possibility of breaking anything inside your Westy and causing a watery mess. When connecting an external water source to this hook-up box, we highly recommend one of our water pressure regulators. Water pressure above 55psi can not only cause damage inside your Westy, but it can also cause the check valve ball in the hook-up to blow out upon disconnecting the water source. Water freezing in the system can do the same, so we recommend always draining the system. To drain the city water plumbing, open the faucet to the city water position and, using a ball point pen, push in on the check valve ball at the hook-up point. Water should drain out sufficiently to keep the system from rupturing under freezing conditions.

Tank Filler

- Reinstall the fill and vent hoses onto the new hook-up the same way they came off the old one. Be sure the hoses are clamped securely and test the connections for leaks before reinstalling to the body of the vehicle.
- To operate, simply install the quick-disconnect fitting on the garden hose and click it onto the hook-up.
- When filling your tank, watch closely and disconnect the hose as soon as you see water appear (5 minutes or less). A bit of leaking from the vent hole after disconnecting is normal and will subside quickly.

(over)

GoWesty Camper Products • 1119 Los Olivos Ave, Los Osos, CA 93402 • (888) 469-3789 • www.gowesty.com



These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

GoWesty Hook-Up Box Installation Instructions

110V Electrical

- The protective box on the back of the old hook-up will be reused; remove it from the old hook-up and reuse the mounting screws to mount it to the new box.
- When hooking up the wires, be sure to put them back in the proper position. The WHITE wire goes to the *silver* terminal screw; the BLACK wire goes to the *brass* terminal screw; the BARE copper wire goes to the *green* terminal screw.

GoWesty Camper Products • 1119 Los Olivos Ave, Los Osos, CA 93402 • (888) 469-3789 • www.gowesty.com



These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

GoWesty Hook-Up Box Installation Instructions

110V Electrical

- The protective box on the back of the old hook-up will be reused; remove it from the old hook-up and reuse the mounting screws to mount it to the new box.
- When hooking up the wires, be sure to put them back in the proper position. The WHITE wire goes to the silver terminal screw; the BLACK wire goes to the brass terminal screw; the BARE copper wire goes to the green terminal screw.

GoWesty Camper Products • 1119 Los Olivos Ave, Los Osos, CA 93402 • (888) 469-3789 • www.gowesty.com