



These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

LED-EXT-VANO-RESISTOR

Exterior LED Bulb Kit Resistor Fix
1980-1991 Vanagon

If you have installed our exterior LED bulb kit and are experiencing issues with your turn signals, install these resistors to eliminate the issues!

Installation Instructions

- 1) Remove the front turn signal housing. Fasten the resistor to the body seam behind the housing.



- 2) Crimp the included piggyback connectors to the resistor wires. Unplug the left and center pin as seen with the socket retaining tab facing away from you. Connect the wires you removed to the piggyback spade terminal and insert the whole piggyback connector to corresponding tabs you removed them from. Reinstall your housing. Repeat the process for the other side!



That's it! You're Ready to Hit the Trails!