



## Engel Fridge/Freezer Installation

**Note:** This kit is designed to work in conjunction with the GoWesty Auxiliary Battery Kit and the SLA1161 or the Odyssey PC1200 battery.

1. Remove driver's seat (refer to Bentley manual, page 72.2).
  - a. If present, swivel seat base 180°.
  - b. Open battery box, and use a piece of tape to hold the lid open.
  - c. Remove the ground cable from the negative terminal.
  - d. Remove the wires from the positive terminal.
  - e. Remove the battery.
2. Remove the metal strip that secures the center aisle carpet.
  - a. Remove e-brake cover.
  - b. Remove center aisle carpet and sound damping pad—these can be removed together if you prefer.
3. Feed the wiring harness provided in the kit through the passenger side of the battery box—follow the wires that go to the seatbelt receiver.
  - a. You can pry the carpet away from the pedestal, and then run the wires behind the carpet toward the floor—or you can simply pull them through the same hole as the seatbelt wires and have them visible.
  - b. Run the wires across the aisle, and then reinstall the sound damping pad and carpet. Cut a small groove in the bottom of the sound-damping pad if you would like it to lay perfectly flat.
  - c. Reinstall the e-brake cover.
4. Reinstall the battery.
  - a. Hook up the positive wires first, making sure to include the red wire from the refrigerator harness.
  - b. Hook up the ground cable and black ground wire from the refrigerator harness to the battery's negative terminal.
5. Reinstall the metal carpet hold-down strip, leaving the two-prong plug accessible at the base of the passenger side pedestal.
6. Attach the refrigerator handles.
7. Replace the passenger seatbelt receiver and seatbelt bolts with the provided eyelet bolts, taking care to make sure that they are nice and tight.
8. Plug in the refrigerator and set it in place.

(con't on next page)

9. If you purchased our GVW-ENGEL-TETHER kit, you'll use the provided hardware to secure your Engel fridge (see photos).



10. Turn on the unit and check to make sure it is running.
11. Close the battery box.
12. If present, swivel the seat base back to the forward position.
13. Reinstall the seat.

Now it's time to enjoy the fruits of your labor.  
We recommend a cold beverage and a secluded camping spot.  
Friends, spouses, dogs, and children are optional. Cheers!