RX-W-SPOUT-KIT

Rotopax Water Container Spout Kit

INSTALLATION INSTRUCTIONS

1. Remove cap and seal from Rotopax to reuse with spout (Fig 1).



Figure 1: Kit parts and pieces reused from Rotopax container



2. Fit seal over adapter flange and insert into neck of Rotopax.



3. Screw down cap over adapter.



4. Screw elbow into adapter, being careful not to cross thread it. Do not overtighten – the adapter will usually seal with only a few threads engaged.



5. Screw spout into elbow. Adjust the angle of the spout by loosening the cap and rotating the elbow. Retighten cap.